

**AD 2 LHSM STANDARD DEPARTURE CHART INSTRUMENT RWY 34**

NAME	PROCEDURE
<b>NALOX3D</b> (39.9)	After departure continue RWY HDG. Climb to FL100. Cross D 5.5 SME DME at 2000 or above then turn left and proceed direct to SME NDB. (Turn limited to 210 KIAS max.) After crossing SME NDB turn left to track 311°. After crossing QDM 162 SME NDB turn left to track 293° proceeding to NALOX. Cross NALOX at FL100.
<b>SUNOR3D</b> (27.9)	After departure continue RWY HDG. Climb to FL100. Cross D 5.5 SME DME at 2000 or above then turn left and proceed direct to SME NDB. (Turn limited to 210 KIAS max.) After crossing SME NDB fly on QDR 151 SME NDB proceeding to SUNOR. Cross SUNOR at FL100.