

AERODROME CHART - ICAO

RWY	DIRECTION	THR	BEARING STRENGTH	TORA	TODA	ASDA	LDA
13R	127°	N47 26 55, E019 13 15	PCN 75R/A/X/T	3009	3009	3009	3009
31L	307°	N47 25 50, E019 15 01	PCN 75R/A/X/T	3009	3009	3009	3009
13L	127°	N47 26 44, E019 15 27	PCN 90R/A/X/T	3707	3707	3707	3707
31R	307°	N47 25 23, E019 17 38	PCN 90R/A/X/T	3707	3707	3707	3707


APRON 1, APRON AG	PCN 60R/A/X/T
APRON 2	PCN 90R/A/X/T
APRON AA, APRON AL	PCN 75R/A/X/T
CARGO APRON	PCN 80R/A/W/T
Taxiways: A1, B1, C, D, J4	PCN 90F/A/X/T
Taxiways: A2-A9, B2-B5, F, K, L, M, N, T, X, Y, Z	PCN 90R/A/X/T
Taxiways: E	PCN 90R/A/W/T

Taxiway width: 23 m, except A1: 18 m.
Remark: TWY A1 downgraded to code C ACFT (max. wingspan 36.00 m).

ARP
N47 26 22
E019 15 43
AERODROME ELEV 496

BUDAPEST APP	122.975	BUDAPEST TOWER	118.100	BUDAPEST APRON 1	131.555
	123.860	BUDAPEST GROUND	121.910	BUDAPEST APRON 2	122.440
	119.510	BUDAPEST DELIVERY	134.540	ATIS	132.380
BUDAPEST INFORMATION (NORTH)			119.350	ATIS (BUD VOR)	117.300

BUDAPEST/LISZT FERENC



FOR BASIC CHART SYMBOLS SEE: GEN 2.3.
INS COORDINATES FOR AIRCRAFT STANDS SEE: PDC CHARTS.
TAXI PROCEDURES SEE: AD 2-LHBP-TAXI CHARTS.
VISUAL DOCKING GUIDANCE SYSTEM:
SAFEDOCK T2 AT PARKING POSITION: 31, 32, 33, 34, 34LR, 35, 35LR, 36, 36R, 37, 38, 39R AND 42, 43, 44, 45.
APRON ELEVATIONS: NOT AVAILABLE.
THE HIGHEST ELEVATIONS OF TDZ: NOT AVAILABLE.
GEOGRAPHICAL COORDINATES FOR TWY CENTRE LINES: NOT AVAILABLE.
OBSTACLES TO TAXING: NOT AVAILABLE.

RWY	TWY	TORA	TODA	ASDA
13L	K	2950	2950	2950
31R	X	2650	2650	2650
	K	705	705	705
13R	C	2450	2450	2450
	B1	1200	1200	1200
	B2	1200	1200	1200
31L	B1	1800	1800	1800
	B2	1800	1800	1800
	C	505	505	505

THIS PAGE IS INTENTIONALLY LEFT BLANK